

SETTING THE «IN-CEILING» PROJECTION SCREEN

- ↑ **Raise the screen:** Press the "Up" button, the screen can be fully opened.
- ↓ **Retract the screen:** Press the "Down" button, the screen can be retracted.
- **Stop the screen:** Press the "Stop" button, the screen can be stopped.

Set the screen low limit

Note: The user must allow the screen to automatically drop to the bottom and stop before acting.

- (1) Long press the "Stop" button of the remote control until the screen makes a "beep" sound to release the button.
- (2) Long press the "Stop" button again, and release the button when the screen makes a long beep. At this point, the original low limit of the screen has been removed.
- (3) Press the "Up" or "Down" button to reach the desired position, press the "Stop" button.
- (4) Press the "Stop" + "Down" button at the same time, and a long beep sound indicates entering mode of "Set a new low limit".
- (5) Press the "Up" or "Down" button to slightly adjust the position. After confirming the position, press the "Stop" + "Down" button at the same time again. A long beep indicates that the new low limit is successfully set.

Set the screen up limit

Note: The user must allow the screen to automatically rise to the top and stop before action.

- (1) Long press the "Stop" button of the remote control until the screen makes a "beep" sound to release the button.
- (2) Long press the "Stop" button again, and release the button when the screen makes a long beep. At this point, the original up limit of the screen has been removed.
- (3) Press the "Stop" + "Up" button at the same time, and a long beep sound indicates entering mode of "Set a new up limit".
- (4) Press the "Up" or "Down" button to slightly adjust the position. After confirming the position, press the "Stop" + "Up" button at the same time again. A long beep indicates that the new up limit is successfully set.

SETTING THE «FLOOR-RAISING» PROJECTION SCREEN

- ↑ **Raise the screen:** Press the " " button, the screen can be fully opened.
- ↓ **Retract the screen:** Press the " " button, the screen can be retracted.
- **Stop the screen:** Press the " " button, the screen can be stopped.

Remote control code pairing

(1) Press and hold the "up" button of the remote control, then turn on the screen after 2 seconds and the screen will beep slowly to enter the code learning mode.

(2) Then release the button, and press the "up" button again, the screen will beep once, and the code pairing is done.

Set the screen height limit

Note: User must allow the screen to rise to the top and stop automatically before operating.

(1) Long press the "stop" button of the remote control till the screen beeps, release the button.

(2) Long press the "stop" button again, when the screen emits a long beep, release the button.

At this point, the original height limit of the screen has been deleted.

(3) Press the "down" button, when it lowers to the position you want, press the "stop" button.

(4) Press the "stop" + "up" button at the same time, a long beep will indicate to enter the mode of setting a new height limit.

(5) Press the "up" or "down" button to adjust the position. After confirming the position, press the "stop" + "up" button at the same time again, a long beep will indicate that the new height limit has been set successful.